TYPE:



INSTALLATION

Secure the base with nails or screws. [11]

Code 1230, 1240: pay attention to the base orientation, the fixing points on the wood must be orthogonal.

Fix the backbox to the base using screws at least 110mm (4.33") long [2]

Open the cable passages where necessary. [3]

Wall the backbox, aligning the edge with the wall, taking into account any plaster. [4]

Remove the wooden parts. [5]

For wiring, refer to the instructions included with the KYKLO appliance.

An accessory bag containing 4 clips for fixing the KYKLO luminaire and a suction cup for its extraction is supplied together with the formwork.

Keep the accessories bag.

Keep these instructions.

ΕET



TYPE:

PROJECT NAME:

INSTALLATION OPTIONS

A - Directly on the wall/ ceiling

B - Recessed, using the backbox cod. 1239 or

1249.



 $\stackrel{\vdash}{\amalg}$ <u>A1</u>: Open the fixture

A2: Drill the base at the specified points and make the electrical connections

A3: Drill the surface and secure the base with the supplied screws. Cod. 1230, 1240: pay attention to the orientation of the eyelid

A5: Close the fixture



TYPE:



B1: Open the fixture

B2: Fasten the supplied clips to the back of the base

B3: Make the electrical connections

<u>B4:</u> Connect the frame ground wire to the base

<u>B5:</u> Close the fixture and insert it into the backbox

