

ANTON

INSTALLATION INSTRUCTIONS

TYPE:

PROJECT NAME:

1. Fixture should be installed on a standard junction box (not provided). Ensure main power is turned off. Install driver in junction box making wire connections to line power.

2. Install crossbar onto junction box with provided screws.

3. Remove backplate from fixture by twisting. Thread wires from driver through hole in backplate. Then place backplate over junction box.

4. Secure backplate to crossbar using provided screws.

5. Connect wires from driver to fixture using Wago connectors.

6. Push excess wire up through hole.

7. Press fixture against backplate lining up mounting pegs with the holes in the fixture. Twist to secure and lock in place.

8. Main power can be turned on.

