CONETM INSTALLATION SHEET

PROJECT NAME:

TYPE:

Connecting and testing the lamps must always be done by an acknowledged electrician according to the locally applying regulations on electric installations. Do not place on a flammable surface. Disconnect from the main supply when fitting lamp or changing bulb.

Fixture mounts to a standard junction box (not supplied).



