

DICE™


INSTALLATION SHEET

TYPE:

PROJECT NAME:

Connecting and testing the lamps must always be done by an acknowledged electrician according to the locally applying regulations on electric installations. Do not place on a flammable surface. Disconnect from the main supply when fitting lamp or changing bulb.

Fixture mounts to a standard junction box (not supplied).



Drill hole spacing:

For Dice S-1 and S-2, drill holes 110mm (4.33") apart.
For Dice M-2 and M-3, drill holes 220mm (8.66") apart.

Dice S-2 shown

INSTALLATION SHEET

Luminart®

WWW.LUMINARTLIGHTING.COM