



CAUTION !!!  
-Lift the structure with delicacy,  
without damaging it

### ASSEMBLY INSTRUCTIONS

- Disconnect the power supply.
- Fix the parts (A) to the ceiling with the screws (X) and plugs (Y) (Fig. 1).
- Screw detail (B) to detail (A) (Fig. 1).
- To adjust the steel cable (D), keep the plunger (R) pressed, position the lamp at the desired height, then release the plunger.
- To adjust the steel cables (E), Unscrew the screw (F).
- Unscrew detail (A) and lower the rose (B). (Fig.2)
- Fix the bracket (C) to the ceiling using the screws (E) and the plugs (D). (Fig.2)
- VER. DIMM. Connect the cables inside the box (V) respecting the indicated polarity (Fig. 2).
- Place the rose window, and screw the particular (A) to the stem (T). (Fig3)
- Screw the safety dowel (K). (Fig.3)

### ATTENTION

The appliances we manufacture are suitable for use in ordinary environments with standard ambient temperature and relative humidity.  
All operations must be carried out by a specialized technician.

### CLEANING

#### Disconnect the power supply or plug from the socket.

For periodic cleaning of the lighting devices, always use gloves and a soft cloth (in the case of smooth surfaces). Never use solvents or alcohol.  
Absolutely avoid bending parts not intended for their mobility as this could weaken or break them

