



INSTRUCTION

- Disconnect the power source.
- Fix To the ceiling the particular (A) with the screw (X) and the dowel (Y) (Fig. 1).
- Screw the clamp (B) in the particular (A). Unscrew the safe (C), push the particular (B1) and regulate the steel cable (D) at the height desired. Screw with care the safe (C) (Fig. 1).
- Unscrew the handle (A) and lower the canopy (B). (fig.2)
- Fix the bracket (C) with screw (D) and dowels (E) on the ceiling. (fig.2)
- Adjust the length of the cable (D) securing the clamp (F). (fig.2)

- ON -OFF VERSION Connect the network cable into the driver (F) according to the polarity. (Fig.2)
- DIMMABLE VERSION Connect the network cable into the terminal (L) according to the polarity. (Fig.3)
- DIAGRAM OF CONNECTIONS DIMMABLE see sheet connection.

- Place the canopy in the ceiling. Screw with care the particular (A) To the pin (T) (fig.4)
- Screw the safety screw (K). (Fig.4)

ATTENTION

The products of our production are suitable for the using in usual surroundings with standard temperature and humidity levels. All the operations have to be done by a technician.

CLEANING:

Switch off the power or pull the plug out.

For the periodical cleaning of the lamp use always gloves and a soft cloth (for glossy surfaces) or a feather duster for the lampshade in fabric or pleated fabric. Don't use aggressive solvents or alcohol.

Avoid absolutely to fold parts which are not expected for folding, in this case welded parts are going to be damaged.

