



### INSTRUCTION

- Switch off the power or pull the plug out.

#### STEP1

- Fix on the ceiling the details (A) with the screws (X) and the dowels (Y) (Fig. 1).
- Screw the detail (B) to the detail (A). Regulate the steel cable (D) by unscrewing the safety (C). Press the little piston (B1) and place the lamp at the wanted height, then release the little piston (B1) and close again the safety (C) (Fig. 1).

#### STEP2

- Unscrew the handle (A) and lower the canopy (B). (Fig.A)
  - Fix the bracket (C) with screw (D) and dowels (E) on the ceiling. (Fig.A)
  - Connect the network cables to terminal (F) according to the polarity, and close the box. (Fig.A)
  - Version Dimmable connect the cables inside the box (V) matching the polarity, and close the box (Fig. A)
  - Tense the power cable paying attention to the regulation , it dosen't have to be too tensed
  - Place the canopy in the ceiling. Screw with care the particular (A), the particular (G).(Fig.B)
  - Insert the lamp on the lamp sockets as version (Fig. 4).
  - Insert the plexiglas finishing panel (N) inside the lamp shade (L) and then lean it by fall on the border of the lampshade (Fig. 2 - 3).
- Attention: in the pleated fabric version the plexiglas doesn't lean on the external border, but it stays 1 cm from the border.
- Attach the plex (N) by turning the handle (P) and the washer (O) at the threaded pipe (M) (Fig. 3).

### ATTENTION:

The products of our production are suitable for the using in usual surroundings with standard temperature and humidity levels.  
All the operations have to be done by a technician.

### CLEANING:

#### Switch off the power or pull the plug out.

For the periodical cleaning of the lamp use always gloves and a soft cloth (for glossy surfaces) or a feather duster for the lampshade in fabric or pleated fabric. Don't use aggressive solvents or alcohol.

Avoid absolutely to fold parts which are not expected for folding, in this case welded parts are going to be damaged.