

INSTRUCTION

- Disconnect the power source.
- Fix the details (A) to the ceiling with the appropriate screws (X) and dowels (Y) (Fig. 1).
- Screw the part (B) to the detail (A). To adjust the steel cable (D), unscrew the safety catch (C) and hold pressed the piston (B1) position the lamp at the desired height, then release the piston (B1) and close the safe (C) (Fig. 1).
- Fix the bracket (C) to the ceiling with the appropriate screws (D) and dowels (E) (Fig. 2).
- Connect the mains cables and the earth cable to the terminal (G) respecting the polarity (Fig.2).
- Position the canopy (B) and close the whole by screwing the part (A) (Fig. 2).
- Screw in the safety dowel (K). (Fig.2)
- To position the plex, screw the parts (P) and the washers (O) (Fig. 3).
- To position the lower closing plex (N) insert the plex inside the lampshade (M) and then place it on the supports (Fig. 4).see versions

PENDANT LAMP 120

- Place the upper Plexiglas panel (Q) by flexing it inside washers (R) (Fig. 5).

ATTENTION:


The safety of this fitting can only be guaranteed if these instructions are observed, during both installation and use. They must therefore be conserved.

The products of our production are suitable for the using in usual surroundings with standard temperature and humidity levels. All the operations have to be done by a technician.

CLEANING:

Switch off the power or pull the plug out.

For the periodical cleaning of the lamp use always gloves and a soft cloth (for glossy surfaces) or a feather duster for the lampshade in fabric or pleated fabric. Don't use aggressive solvents or alcohol. Avoid absolutely to fold parts which are not expected for folding, in this case welded parts are going to be damaged.



2 installers

WEIGHT
4.5kg - 9.92 lb