

RADAR


INSTALLATION INSTRUCTIONS

TYPE:


PROJECT NAME:




Choose the mounting point




A




B




C




E




F




D



G



H




JUNCTION BOX

DRIVER

CROSSBAR

CANOPY

K




I

L


CONNECT FIXTURE CABLE TO 24V DRIVER

J

M



N



INSTALLATION SHEET

Luminart®

WWW.LUMINARTLIGHTING.COM

RADAR

INSTALLATION INSTRUCTIONS

TYPE:

PROJECT NAME:

