


WIRING DIAGRAM


DIMMING 120V ONLY
TRIAC (LTE)



FIXTURE CABLES

WIRING DIAGRAM

DIMMING 120-277V
0-10V



FIXTURE CABLES

*Junction box for reference only

1. Turn off the power.
2. Attach the mounting bracket to the mounting crossbar with screws (A) and mount the crossbar to the junction box.
3. Adjust the length of the wire and lock it with the end stop. You can store the excess cable in the jbox or cut off the extra length.
4. Connect the 120-277V power to the driver. Remember to ground (electrical wiring diagrams on the first page).
5. Use the blocks to screw the base to the mounting bracket.
6. Turn on the power.

Note: The enclosed tool kit is designed for solid materials (solid brick, wood, concrete, aerated concrete) and gypsum board surfaces. The dowel should be properly matched to the mounting surface. Proper use of the dowel affects the safety and strength of the structure.

